

Worktops, splashbacks
and upstands exclusively
manufactured by

BB
BUSHBOARD

***New 3 year
warranty
against
blown joints!***



BB complete 
colour matched worktop adhesive

jointing sealing bonding finishing



The complete solution

One job, one cartridge

New 3 year warranty*

With BB Complete all worktop joints are guaranteed for 3 years against moisture ingress and expansion. Get the benefit of total peace of mind on all your worktop installations.

- New 80ml cartridge for 3 joints
- 6 most popular colours now in an easy-to-use syringe style cartridge
- Brand new advanced formulation for superb results

- Easy and flexible to work with for bonding, sealing and finishing
- Choice of 20 colour matches to suit over 100 designs
- Comes in a C90 cartridge for standard glue gun

For full details see our trade web site or ask for a copy from our Customer Service Team on 01933 232272

* This 3 year warranty applies only to Bushboard Prima, Omega and Odyssey worktops when installed in residential environments and which have been subject to fair wear and tear. BB Complete must be used in accordance with our recommended installation instructions. A proof of purchase for adhesive and worktops will be required in the event of a query.

User guide



Jointing

Preparation

Ensure all surfaces are cut accurately, clean, dry and completely free of dust.

Well cut joints which fit tightly will ensure an inconspicuous finish.

Biscuits will ensure strong level joints. Always use connector bolts to assure strength.

Cut bolt slots no deeper than 25mm from the rear surface for 40mm worktops.

Assembly

BB Complete has a joint open time of 10-15 minutes allowing more time to make adjustments.

Apply a continuous 5mm diameter bead around the border of one cut edge, 5mm in from the bottom and top faces following the profile and

completing a loop. Use plenty of adhesive, making sure you do not reduce the amount of adhesive recommended.

Insert the connector bolts and tighten to the nip point, ensuring that BB Complete squeezes out around the entire joint including the bottom face.

Check the joint is level, adjusting as necessary using a rubber mallet.

Fully tighten the bolts a maximum of two full turns past the nip point.

Using a soft plastic or laminate scraper, remove excess adhesive avoiding smears. Take care not to scratch the surface particularly with gloss finish worktops.

Moisten a clean, lint-free cloth with white spirit and carefully remove the residue, wiping at 90° across the joint to avoid removing adhesive before the joint cures.

Do not wipe down with water or any other solvents and allow 24 hours for the joint to fully cure before using.

Sealing

For all areas where raw chipboard has been exposed, such as sink cut-outs and cut ends, spread a bead of BB Complete using a spatula ensuring total coverage.

To seal a worktop to a wall ensure all surfaces are fully dry, dust free and stable.

Apply a generous bead of BB Complete along the back edge of the worksurface ensuring there are no gaps.

Smooth the bead using a spatula or use a rubber gloved finger dipped in white spirit.

Allow to cure for 24 hours before use.



Bonding

Upstands

Ensure that all surfaces are fully dry, dust free and stable before bonding.

Apply three beads along the length of the upstand and a generous seating bead along the bottom raw chipboard sufficient to ensure the upstand is totally sealed against moisture ingress.

Clean away any excess with a clean wipe moistened with white spirit. Do not use water or other solvents. See “finishing” instructions to add a final waterproof seal between the upstand and worktop.

Allow to cure for 24 hours before use.

Splashbacks

Ensure that all surfaces are fully dry, dust free and stable before bonding.

Dot and dab BB Complete to the back of the splashback and apply a generous seating bead along the

bottom raw MDF, sufficient to ensure the splashback is totally sealed against moisture ingress.

Clean away any excess with a clean wipe moistened with white spirit. Do not use water or other solvents.

See “finishing” instructions to add a final water proof seal between the splashback and worktop.

Allow to cure for 24 hours before use.

Finishing

The standard nozzle is designed to produce a fine bead.

Consider masking the area to be finished with a good quality masking tape to produce a neat straight edge.

Hold the nozzle at a 45° angle and apply an even bead along the area to be finished.

Shaping of the bead is possible using a specialist smoothing tool, or simply

using a rubber gloved finger dipped in white spirit. Do not use water or other solvents.

Once satisfied with the final finish any masking tape should be peeled away immediately.

Clean away any spillage with a clean wipe moistened with white spirit. Do not use water or other solvents.

Allow to cure for 24 hours before use.

Aftercare

BB Complete is designed to produce strong waterproof joints. However it is advised that the home owner takes care with heat radiating appliances or excess moisture. Do not site kettles, toasters, deep fat fryers or other heat generating small appliances over joints. Wipe up and dry all spills immediately. Taking good care of your worksurfaces will ensure they give many years’ service.

prima



2381	Amber Granite	80ml	Vanilla	6219	Espresso	80ml	Chocolate	0215	Natural Block Walnut	80ml	Fudge
6227	Amber Kashmir	80ml	Fudge	3465	Golden Mascarello	80ml	Fudge	6257	Olympus	80ml	Chocolate
4612	Amber Slate	80ml	Fudge	2510	Golden Morning Oak		Toffee	2843	Paradise Granite	80ml	Fudge
3466	Antique Mascarello		Mushroom	4874	Granite Black Brown		Basalt Grey	3522	Perlato Granite		Pewter Grey
4615	Beech Butcher Block		Oatmeal	4610	Green Lalique		Sage Green	1340	Polar White	80ml	Ice White
2699	Black Granite	80ml	Jet Black	0332	Himalaya	80ml	Vanilla	2743	Sandgrain		Ivory
7178	Black Quasar	80ml	Jet Black	5212	Ice		Ash Grey	6220	Smoke		Basalt Grey
2935	Blue Carpathia		Slate Grey	6242	Italian Marble	80ml	Vanilla	6233	Soft Walnut Blocked	80ml	Chocolate
1673	Blue Magma		Slate Grey	6218	Latte	80ml	Vanilla	1782	Stardust		Basalt Grey
3467	Blue Storm	80ml	Chocolate	1936	Lava Dust		Silver Grey	0331	Toscana	80ml	Chestnut
8071	Brushed Aluminium		Silver Grey	6506	Madrid Jade	80ml	Chocolate	5726	Utopia Granite	80ml	Fudge
1793	Champagne Haze		Ivory	2851	Malachite Carpathia		Sea Green	1790	Warm Haze	80ml	Fudge
3812	Cherry Butcher Block	80ml	Chestnut	4120	Millstar Cream		Silver Grey	6228	Wenge Blocked	80ml	Chocolate
5850	Classic Onyx		Ivory	4121	Millstar Grey		Silver Grey	0333	Woodmix		Oatmeal
3855	Clear Maple	80ml	Vanilla	0330	Monseerratt	80ml	Chocolate	6235	Zebrano Blocked	80ml	Chocolate
4536	Cornish Granite		Ivory	2726	Natural Beech	80ml	Vanilla				

omega

A040	Antares		Basalt Grey	C025	Craquele		Ivory	L003	Midnight	80ml	Jet Black
A017	Antique Block Walnut	80ml	Chestnut	C037	Crystal	80ml	Ice White	D010	Mocca	80ml	Chocolate
A024	Aticos Gold		Ivory	D017	Dakota		Basalt Grey	N005	Noir	80ml	Jet Black
A078	Aztec Granite	80ml	Chestnut	D020	Dolmen		Mushroom	N023	Nova Saphir		Airforce Blue
B056	Bahia Beige		Ivory	B107	Ebony Stripwood	80ml	Chocolate	O076	Olivewood	80ml	Chestnut
B066	Baltic Granite	80ml	Chocolate	E046	Etna Verde		Sea Green	O063	Opus Coral	80ml	Vanilla
H018	Beech Normande	80ml	Vanilla	W018	Figured Wenge	80ml	Chocolate	P065	Puno	80ml	Chocolate
G046	Beige Granite		Ash Grey	G011	Granito Fonce		Silver Grey	F072	Ruby Quartz		Cherry Red
B039	Black Alaska	80ml	Jet Black	149	Gris Paloma *		Silver Grey	X033	Silverfrost		Pewter Grey
B070	Blanc Megeve	80ml	Ice White	I010	Iquitos Noir		Slate Grey	S065	Solok		Slate Grey
B050	Butcherblock Medium		Toffee	K050	Kashmir Gold		Mushroom	H030	Steamed Beech		Toffee
C080	Cap Horn		Slate Grey	K002	Kota	80ml	Fudge	S030	Strass Blanc	80ml	Ice White
C012	Carthage	80ml	Ice White	L011	Light Blocked Walnut		Toffee	S033	Strass Noir	80ml	Jet Black
C110	Charcoal		Slate Grey	L032	Lima	80ml	Jet Black	T028	Texas Brun		Chestnut
F073	Chocolate Quartz	80ml	Chocolate	P015	Limestone	80ml	Vanilla	F070	Vanilla Quartz	80ml	Vanilla
F071	Cinder Quartz	80ml	Chocolate	M001	Maryland Clair *		Silver Grey	V002	Venise		Olive Green
C030	Cosmic Beige	80ml	Vanilla	M003	Maryland Fonce		Basalt Grey				

* available in Odyssey only

All colours available in 290ml cartridges. 80ml indicates the colour is available in a handy 80ml/3 joint cartridge

80ml	Jet Black	Slate Grey	Basalt Grey	Silver Grey	Ash Grey	Pewter Grey	80ml	Ice White	Ivory	80ml	Vanilla	Oatmeal
80ml	Fudge	Mushroom	Toffee	80ml	Chestnut	80ml	Chocolate	Sea Green	Olive Green	Sage Green	Airforce Blue	Cherry Red

For technical support on Bushboard products, please contact the Customer Service Team on:
tel: 01933 232 272
fax: 01933 232 286
email: samples@bushboard.co.uk
or log onto www.bushboard.co.uk

